



Group 5 – FindFit

19th November 2021

Agenda

01

Introduction

Problem Statement, Brief
Description of Solution

02

Details of Approach

IOT Architecture, Model

03

Implementations & Demo

Sensor Management,
Demo

04

Challenges & Limitations

Challenges faced,
takeaways





I. Introduction




FindFit

- Simple Mobile Application
- Predicts exercise type
- Updates with exercise changes



Solution Overview





2. Details of the approach including IoT architecture, ML model




Client


Battery Level

Start Button
Exercise Timer

Prediction
Stop Button



Backend Server



Backend Server


SERVER
POST - api/v1/predict



POST request - *api/v1/predict*
JSON = { 0: {data}, 1: {data}..., 33: {data} }



Classification



Swift App
GATEWAY



Backend Server



SERVER

POST - api/v1/predict



- 1 POST request received by - *api/v1/predict*
JSON = { 0: {data}, 1: {data}..., 33: {data} }
- 2 Convert the JSON data into a 1x1x33 numpy array
- 3 Pass the converted data into the ML Model to obtain the classification.
- 4 Return the response as a JSON

ML Model

Data Manipulation

To sanitize
and augment
data



Data Collection

- Self-collected via a Python Script
- Stored in a PostgreSQL database

Model Experimentation

- MLP
- LSTM
- CNN



Data Collection



1

Sensor mounted on the wrist

3.33_{hz}

Sampling Frequency

- Non-standardized recording length
- Unique Session IDs
- Stored in PostgreSQL Database

Data Manipulation




- 1 For each time-series, the initial and end were trimmed to account for movement recorded to begin and stop the recording process.
- 2 Rows containing zero-values were dropped as they represent periods of idleness.
- 3 A rolling window of ~ 10 s was then applied to the time-series to synthetically generate more data for training.


Other Possible Augmentations Considered:

- Step-Wise Windows
- Hamming Windows
- Time-series Elongation/Compression
- Min-Max Scaling

Model Experimentation



Model Experimentation





3. Implementation Details and Demo



Implementation Details

2

Sensors on

3.33Hz

Sampling frequency

Core Bluetooth, Restful API and Flask


Communication protocol

Power Management


Controlling the sensors to be turned on ->
Controlled via Swift UI

```
if SensorTag.validConfigCharacteristic(characteristic: thisCharacteristic) {  
    // Enable Sensor  
    var enableValue = thisCharacteristic.uuid == MovementConfigUUID ? 0x7f : 1  
    let enableBytes = NSData(bytes: &enableValue, length: thisCharacteristic.uuid == MovementConfigUUID ? MemoryLayout<UInt16>.size :  
        MemoryLayout<UInt8>.size)  
    self.sensorTagPeripheral.writeValue(enableBytes as Data, for: thisCharacteristic, type: CBCharacteristicWriteType.withResponse)  
}  
// print(characteristic.uuid)
```

THE DEMO



Video (In case real life didn't work)



Link: <https://youtu.be/XFoTEagM7gg>



5. Summary including challenges faced, limitations of the solution, possible future directions etc.


Challenges faced

- Default RTOS project does not come with BLE stack
- Tried to run customised firmware using BLE stack
 - BLE no native support for non-Windows users
 - Different versions of compiler required
 - Lack of solid documentation
 - Lack of examples
- Unable to optimize sensortag well with SWIFT client
 - Power policies exist in RTOS library but not available in SWIFT
 - Default firmware uses polling
 - Unable to optimize idling/sleeping of device




Limitations of solution

- Lack of cross platform support
- Expensive API call
- Setup not ready for production



Possible future directions

- Implement code on lower level using RTOS
- Abstract layer for different clients to consume
- Websocket for prediction
- Production ready server



THANK YOU

CREDITS: This presentation template was created by Slidesgo, including icons by Flaticon, infographics & images by Freepik

Please keep this slide for attribution